



1. Product Name


LED Colour Changing Ceiling Ring Medium

2. Product Code

05267083

3. Color

Comme illustré



4. Short Description

Let yourself be amazed by this circular ring that transforms your ceiling with beautiful colour-changing effects.

5. Contents

1x round LED lamp

4 x chain connected with screw ring

1x ceiling mount, attached to the metal canopy of the ceiling

1x remote control (requires 2 AAA batteries, not included)

Wall plugs and screws

1x replaceable power adapter

Required tools:

Phillips screwdriver and drill

6. Sensory Stimulation

See

7. Specifications

Specifications for CCCRM – Medium Ring

Dimensions: 39,5 cm x 10cm

Weight: 1,24kg

Input: 100-240V – 0.6A Max 50/60Hz

Output: 12V 2.0A

50 non-replaceable RGB LEDs 9.6W





8. Safety

Warning! Contains flashing light sequences that may affect individuals with light-sensitive epilepsy or other light sensitivities.

Safety warnings:

- Before installation, ensure that the product is not damaged. If any part of the product is damaged, do not attempt to assemble or use it.
- Do not attempt to connect this product to the mains electricity. This product does not need to be directly connected to your electrical supply. It works with a power adapter.
- Only use the adapter provided with this product; no other adapter should be used.
- This product contains non-replaceable LEDs. If one of the LEDs stops working, the entire unit must be disposed of according to your local guidelines.
- This is an electrical product – not a toy! To avoid the risk of electric shock, fire, burns, or injury, do not let it come into the hands of small children or place it where they can reach it. Cables and wires must be kept out of the reach of children.
- As with all electrical products, precautions must be taken during handling and use to prevent electric shock.
- Ensure that the cables are laid out in such a way that no tripping, entangling, or choking hazard exists.
- Do not use the packaging material.
- Keep away from heat sources or open flames.
- For indoor use only. Avoid using it in damp or wet conditions and prevent contact with water.
- Regularly check to ensure that fasteners, accessories, and installations are not loose.
- Installation should only be performed by a competent, qualified installer. It is recommended to hire professionals with experience in designing sensory rooms.

9. Installation

- Carefully read these instructions before you begin and keep them for future reference. Check the contents of the package and make sure all required parts are present and no parts are missing. If any parts are missing, DO NOT attempt to assemble the product.
- Carefully remove the product from the packaging and make sure the cable is not twisted or tangled. The chains may be tangled with each other, so carefully untangle them.
- Since this lamp does not require wiring, an adapter is included. Ensure that a power socket is within reach without overstretching the cable.





1. To remove the bracket from the metal canopy, remove the screw cap and nut from the base.

2. Use the mounting bracket as a template to mark the screw holes on the ceiling.



3. Drill a hole in the wall/ceiling at the marked spots to the required depth using the appropriate masonry drill bit. Insert the wall plugs. Press the wall plug against the wall and insert the screw into the plug.


4. Use the appropriate expansion screws and fasteners to secure the bracket to the ceiling. Screws and wall plugs are included but may not be suitable for all wall/ceiling types. Assess the strength of the wall/ceiling where you intend to mount the lamp and use the appropriate fixings. Use a cable, pipe, and beam detector to find safe mounting positions.



5. Attach the metal bracket to the wall/ceiling.



6. Place the hanging round lamp on a flat surface. There are 4 small pre-drilled holes around the lamp. Screw an eye bolt, attached to the chain, into each hole. This can be done by hand. Do not screw the bolt fully into the lamp; only screw it in until the threading disappears into the ring light.



7. Once the four hanging chains are securely screwed into the round lamp, check that the other end of the chains is firmly attached to the metal ceiling canopy. The metal chains are interconnected, allowing you to adjust the length/height of the hanging lamp according to your preference. Do this before attaching the metal ceiling canopy to the mounting bracket.



8. Align the metal cap with the protruding screws on the fixed metal bracket, then insert the nut and the screw cap to secure the bracket in place along with the metal cap.



9. Connect the power adapter to the socket of the hanging lamp.
10. Plug the adapter into the power supply and turn it on.

Keep these instructions as they contain important information.

For more information, please visit our website www.nenko.com

