

## 1. Product name


LED Colour Changing Ceiling Ring Large

## 2. Product code

05268083

## 3. Colour

As illustrated



## 4. Brief description

Let yourself be amazed by this circular ring that transforms your ceiling with beautiful colour-changing effects.

## 5. Contents

1x round LED light  
4 x chain connected with screw ring  
1x eiling bracket, fixed to the metal canopy of the ceiling  
1x remote control (requires 2x AAA batteries, not included)  
Wall plugs and screws  
1x interchangeable power adapter

### Required tools:

Phillips screwdriver and a drill.

## 6. Sensory stimulation

See

## 7. Specifications

### Specifications for CCCRL – Large Ring Light

Dimensions: Ø100cm x 10cm  
Weight: 3,32 kg  
Input: 100-240V – 0.6A Max 50/60Hz  
Output: 12V 2.0A  
Material: PE  
150 non-replaceable RGB LEDs 9.6W  
Chain length: 88 cm  
Cable length between the metal canopy and the ring light: 88 cm  
Adapter cable length, including the jack: approx. 154 cm





## 8. Safety

**WARNING!** Contains flashing light sequences that may affect individuals with photosensitive epilepsy or other light sensitivities.

### Safety warnings:

- Before installation, ensure that the product is not damaged. If any part of the product is damaged, do not attempt to assemble or use it.
- Do not attempt to connect this product to the power supply. This product does not need to be directly connected to your mains power supply. It operates with a power adapter.
- Only use the adapter supplied with this product; no other adapter should be used.
- This product contains non-replaceable LEDs. If any of the LEDs no longer work, the entire unit must be disposed of according to your local municipality's guidelines.
- This is an electrical product – not a toy! To avoid the risk of electric shocks, fire, burns, or personal injury, it must not be handled by or placed within reach of young children. Cables and wires must be kept out of reach of children.
- As with all electrical products, precautions must be taken during handling and use to avoid electric shocks.
- Ensure that cables are arranged so that there is no risk of tripping, entanglement, or strangulation.
- Do not use the packaging material.
- Keep away from heat sources or open flames.
- For indoor use only. Avoid using in damp or wet conditions and prevent contact with water.
- Perform regular checks to ensure that fastenings, fittings, and installations are not loose.
- Installation should only be carried out by a competent, qualified installer. It is recommended to hire professionals with experience in designing sensory spaces.

## 9. Installation

- Read these instructions carefully before you begin and keep them for future reference. Check the contents of the package and make sure all required parts are present and no parts are missing. If parts are missing, DO NOT attempt to assemble the product.
- Carefully remove the product from the packaging and ensure that the cable is not twisted or tangled. The chains may be tangled, untangle them carefully.
- Since this lamp does not need to be wired, an adapter is included. Ensure that a power outlet is within reach, without stretching the cable too much.





1. To remove the bracket from the metal canopy, remove the screw cap and the nut from the base.

2. Use the mounting bracket as a template to mark the drill holes on the ceiling.

3. Drill a hole in the wall/ceiling at the marked spots to the required depth using the appropriate masonry drill bit. Insert the wall plugs. Press the plug against the wall and insert the screw into the plug.



4. Use the appropriate expansion screws and fittings to secure the bracket to the ceiling. Screws and wall plugs are included, but they may not be suitable for all wall/ceiling types. Assess the strength of the wall/ceiling where you intend to mount the light and use the appropriate fixings. Use a cable, pipe, and stud detector to find safe positions for mounting



5. Attach the metal bracket to the wall/ceiling.



6. Place the hanging round lamp on a flat surface. There are four small pre-drilled holes around the lamp. Screw an eye screw, which is attached to the chain, into each hole. This can be done by hand. Do not screw the screw completely into the lamp; screw it in just enough so that the threading disappears into the ring light.



7. Once the four hanging chains are securely screwed into the round lamp, check that the other end of the chains is firmly attached to the metal ceiling bracket. The metal chains are linked together, allowing you to adjust the length/height of the hanging lamp according to your preference. Do this before attaching the metal ceiling bracket to the mount.



8. Align the metal cap with the protruding screws on the fixed metal bracket, then insert the nut and screw cap to secure the bracket in place along with the metal cap.



9. Connect the power adapter to the socket of the hanging lamp.
10. Connect the adapter to the power supply and turn it on.

Keep these instructions as they contain important information.

For more information, please visit our website [www.nenko.com](http://www.nenko.com)

