



1. Productname

Nenko Interactive - Mirror ball spot LED

2. Product code

14785111

3. Description

LED Discospot with colour change for use with a mirror ball. This disco spot works together with the Nenko Interactive wireless colour switch panel (22009). Change the colour of the spot at the touch of a button.

Not only the colour of the disco spot will change, but also all other products of the Nenko Interactive range. Colour black. Weight: 0.65 kg.

Dimensions: 17.5 x 8.5 x 14.3 cm



4. Colour

See picture

5. Sense stimulation

See

6. Installation



The product is plug and play. You only need to plug in and it works. If the spot does not respond with the switch panel, the menu is set incorrectly.

You set the menu as follows:

1. Press the "menu" button.
2. Press up or down until the screen says "A001".
3. Press "enter."

Für weitere Informationen besuchen Sie bitte unsere Website www.nenko.de

