



## 1. Name of the product

Time Timer Medium & Large

## 2. Product code

19444471 & 50031471

## 3. Colour

Black with white and red



## 4. Short description

Use the Time Timer to learn the concept of elapsed time, to use time efficiently, to keep track of time during activities, or to encourage independence. The timer is a visual timer that can be used without even knowing time. At home and in daily life the Time Timer has many applications that help everyone become more productive, more organized and more relaxed during the day.

## 5. Product specifications

Specifications Medium:

Size: 20 x 20 cm

Batteries: 2x AA

Specifications Large:

Size: 30 x 30 cm

Batteries: 1x AA

## 6. Replacing batteries

To install the AA battery in your Time Timer Original Medium and Large:

1. Open the battery compartment on the back of your Timer.
2. Find the ribbon inside the battery compartment and pull it over the words "Made in China."
3. Insert the AA battery with the positive (nub) end first into the compartment OVER the ribbon.
4. Place the cover back on the battery compartment. The ribbon should stick out.
5. When you're ready to replace the battery later, simply open the battery compartment and tug on the ribbon to easily pull the battery loose.





To install the AA batteries in your Time Timer<sup>®</sup> Original Medium and Large Update:

\*The update requires 2 AA batteries and includes a shallower battery compartment for easier battery replacement.

1. Open the battery compartment on the back of your Timer.
2. Insert the AA batteries with the positive (nub) end first into the compartment.
3. Place the cover back on the battery compartment.
4. When you're ready to replace the battery later, simply open the battery compartment and tug on the ribbon to easily pull the battery loose.



For more information, you can visit our website [www.nenko.com](http://www.nenko.com)

