



1. Product name

Rotating colour spectrum light panel

2. Product code

26010477

3. Color

As shown

4. Short description

Turn the rods and watch the colours change! This wall panel creates a playful and calming visual effect. Easy to use and perfect for sensory rooms, classrooms, and nurseries. Made from durable materials for long-lasting enjoyment.



5. Content

1 x Panel
1 x Adapter
1 x Drilling template paper
A bag of screws
Required: Drill

6. Sensory stimulation

See and Feel

7. Technical specifications

Size: 120 x 30 x 5 cm (approx.)

Weight: 7.2 kg

LED: 87 non-replaceable multicolor LEDs 10W

Input: AC100-240V 50/60Hz Output: DC 5V 2A

WARNING: All provided dimensions and weights are approximate.

8. Installation

1. Carefully unpack the product, remove the contents, and place them on a cardboard or another protective surface to avoid damage. Ensure that all the listed contents are present before proceeding with the installation.

2. Since this product does not require wiring, an adapter is provided. Therefore, ensure that a power outlet is within reach without stretching the cable too much.





3. It is recommended to mount the panel on the wall. Make sure that the wall where you want to install the panel is suitable and can support the weight of the panel. Use the appropriate fixtures and accessories that are suitable for your wall type.
4. A screw marking paper is provided, which matches the screw pattern of the panel. Use it as a reference to easily drill a hole for the screws in the wall. Then, insert the plugs and screws..
5. Plug the adapter's connector into the DC port on the side of the panel. Connect the adapter to the power outlet and turn it on. The on/off switch on the front of the panel can be used to turn the panel on or off.
6. Turn the disks to change/activate the color, creating the desired pattern.

Keep these instructions as they contain important information.

9. Safety

Warning! This product should only be used under the direct supervision of a responsible adult.

Safety warnings:

- Read these instructions carefully before starting and keep them for future use. Check the contents of the packaging and make sure all necessary parts are present and none are missing. If parts are missing, do not attempt to assemble the product.
- Check the product for damage before installation. If any part of the product is damaged, do not attempt to assemble or use it.
- Do NOT attempt to connect this product to the power grid. It operates with an adapter.
- Only use the adapter provided with this product and do not replace it with another one.
- This product contains non-replaceable LEDs. If any of the LEDs stop working, the entire device must be disposed of according to your local municipality's guidelines.
- Do not attempt to open the device, as this could cause further damage.
- Remove all packaging materials before installation. Do not use the product while it is still in the packaging. Keep the packaging out of reach of children and pets.
- Keep it away from heat sources or fire.
- For indoor use only.
- Keep it away from water or other liquids. Keep it dry.
- Make sure the cable is placed in such a way that there is no risk of tripping, entanglement, or strangulation.
- Always unplug the product when not in use.





- Regularly check to ensure that the cables are still properly connected, the device is not damaged, and it is securely mounted.
- Do NOT pull on the panel.



Disposal: The "Crossed-Out Wheelie Bin" symbol on the product indicates that it is classified as electrical or electronic equipment and should not be disposed of with other household or commercial waste at the end of its life. The product must be disposed of according to your local municipality's guidelines.

For more information, please visit our website www.nenko.com

