



1. Product name

Musical abstract tactile panel

2. Product code

29204085

3. Short description

The tactile music panel is a beautifully designed interactive panel that invites users to explore sounds, rhythms and textures. This versatile panel offers a unique combination of musical and sensory stimulation and is ideal for care homes, schools, nurseries and other environments where sensory experience and development are key.

4. Sensory stimulations

Seeing, feeling and hearing

5. Product specifications

90 x 90 x 8,4 cm – 15 kg

6. Assembly

1. Place the suspension brackets on the back of the tactile panel.
2. Drill holes in the wall 830 mm apart and insert 6 mm plugs.
3. Insert 30 mm screws into the dowels and hang the panel.
4. Mark drill points through the fixing holes in the lower corners of the panel.





5. Remove the panel and drill at the marked points. Then insert the 7 mm plugs.
6. Hang the panel again and insert the 70 mm screws, together with the screw caps, into the fixing holes.
7. Press the screw caps closed when finished.

7. Maintenance

If the product needs cleaning, use only a soft, damp cloth.

DO NOT use harsh chemicals or abrasives.



For more information, you can visit our website www.nenko.com

