


Replacing bulb bubble tube

Loosen the cap by unscrewing the screws. There is 1 screw on each side.



lift up the hood. You can now see the inside.





Pull out the green terminal block (Red arrow) and unscrew the bulb (green arrows)

Then put the new bulb back in and follow the steps in reverse order.

