



## 1. Product name

Nenko Interactive - Step in wallpanel Infinity

## 2. Product code

95063085

## 3. Short description

Discover the magic of the Sparkling Deep Mirror Panel! This innovative panel offers an enchanting experience with an array of effects and vibrant rainbow colours. It is designed to create a safe and stimulating environment, perfect for both children with autism and those without disabilities

## 4. Product specifications


Height: 50 cm

Width: 50 cm

Thickness: 6 cm

Weight: 3.0 kg

## 5. Assembly



On the back of the panel you will find 2 hanging brackets. These are spaced 435 mm apart (centre to centre). Simply screw 2 screws into the desired mounting surface, at the correct distance, and hang the panel in place.


Once it is in place, the power cable and adapter plug can be plugged in and switched on.





## 6. How to use

On the side of the panel, you will find the panel's controls:



### 1. On/off switch

This toggle switch is used to turn the panel on and off.

### 2. Speed button

This button is used to control the speed of the LED patterns on the panel. The panel has 3 speeds (slow, medium and fast). When you press this button, the panel moves to the next speed. Each time you press this button, the speed is increased until it spins again.

### 3. Pair button

This button is used to change the product's pairing channel if you want it to communicate only with specific devices. Press and hold this button for 10 seconds to enter pairing mode. The panel flashes continuously in this mode. A compatible remote control can now be used to set the pairing channel.





Use the robust button on the front of the panel to cycle through the LED patterns. With each press of the button, you move to the next pattern.



A compatible remote control can also be used to operate this panel and change the LED colours (22009134 & 22011134).

## 7. Troubleshooting

The depth mirror panel is designed with low maintenance in mind.

If problems occur:

- Switch off the panel, unplug it and check that the power cable is correctly plugged into the back of the unit (see below).



- Switch off the panel, unplug it and leave for 1 minute to perform a reset. After this time, plug back in and turn the panel back on.





## 8. Maintenance

If the product needs cleaning, use only a soft, damp cloth.

**DO NOT** use harsh chemicals or abrasives.

### Electrical specifications

INPUT: 100-240V 50/60Hz, 0.7a

OUTPUT: 5V 3A

For more information, you can visit our website [www.nenko.com](http://www.nenko.com)

