



1. Name of the product

Luminous discovery table

2. Product code

97980036

3. Short description

Combining functionality with visual appeal, this sturdy, illuminated plastic table provides soothing lighting that is ideal for use in a variety of settings, including sensory rooms and therapeutic settings. Whether indoors or outdoors, this sturdy yet lightweight table is easy to move, easy to clean, and perfect for both individual and group activities. With its stylish design, the table is not only practical but also a beautiful addition to any space.

4. Sensory stimulations


See

5. Use

- Select the correct charging adaptor (UK/EU/US/AU).
- Open the rubber cover charging socket on the base and plug in the charger.
- Always charge with the light in the OFF position.
- If light comes on during charging, use the ON/OFF button on the base to turn it OFF.
- Charge for 8-10 hours, unplug the charger and replace the rubber cover before use.
- Do not use continually with the charger connected to the mains



Remote Control Instructions



6. Technical information

- (IP65 rated) Light unit suitable for indoor or outdoor use.
- Operating time 5-10 hours (depending on program setting).
- Charger Input - AC 110V-240V 50/60HZ - Output DC5V.
- Battery replacement for remote: CR2025 Lithium Button Cell.

7. Safety

- Suitable for use with children under adult supervision. This is not a toy.
- Power adapter & remote are not waterproof, keep away from water.
- In fast flashing or strobe mode the light source may potentially trigger seizures with children that have a history of photosensitive epilepsy.
- Remote contains button battery - Keep new and used batteries away from children. Dispose of used batteries immediately. A button battery can cause serious injuries if it is swallowed or placed inside any part of the body. If you think that batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Please retain this information for future reference.





8. Trouble Shooting

- Light flashes uncontrollably – this means the battery is very low. Allow the light to flash until it goes OFF and then charge fully for 8-10 hours.
- Extend battery life by charging when power is low, rather than allowing light to become completely exhausted. Usage time will reduce when running Flash/Strobe/Fade/Smooth program.
- Remote not responding but light can be turned ON/OFF manually at the base – check that clear pull tab has been removed from the remote battery housing. Check the condition of the button cell, the + should be facing upwards

For more information, you can visit our website www.nenko.com

