



1. Name of the product

Nenko Interactive - Bubble tube 200 x 20 cm

2. Product code

19776095

3. Color

As illustrated

4. Short description

Bubble Tubes are essential in any Sensory Room. Our Bubble Tubes are:

- visually attractive due to the changing, colored light
- soothing due to the movement of the bubbles
- relaxing due to the heat and vibration of the tube
- maintenance-friendly due to the LED lighting

Add a Nenko Interactive switch and wirelessly control the colors and bubbles of the bubble unit and put all Nenko Interactive products in the room in the same color!

There goes about 52 liters of water in this Bubble Tube.



5. Contents

1x Bubble Tube

1x Bubble Base

(Excluding bracket for Bubble Tube)

6. Sensory stimulation

Sight

7. Use

- Before you can use the Bubble Tube, you have to check if the surface is stable/flat.
- Unpack the Bubble Tube carefully.
- Fill the Bubble Tube with ½ liter of distilled water, check if the Bubble Tube and hose-connection are settled and shut.

8. Technical Specification

Dimension : 200 x 20 cm

Base: 43 x 35 x 12,5 cm





9. Installation

- The Bubble Tube is for indoors use only.
- Please ensure that the Bubble Tube cannot be knocked over.
- Fill the Bubble Tube up to 40 mm from the top.
- Pay attention! Do not spill water on the base while filling the Tube.
- The Tube can only be cleaned with a damp cloth. (DO NOT USE CLEANSER)
- Because of the evaporation of the water, it is normal to refill the Bubble Tube regularly.
- Over time the water can be murky. It is advised to check water clarity and quality regularly. You have to empty the entire Bubble Tube, clean it thoroughly, and fill it again.

Control the air flow

At the back of the Bubble Tube is a turning knob. The air volume can be determined by this knob. To reduce the bubble flow, turn the knob clockwise. In order to raise the bubble flow, rotate the knob counter clockwise.

10. Troubleshooting

Despite of careful assembly and checks it might be possible that the Bubble Tube is not completely waterproof. You have to check the Bubble Tube for damage before using it. It is advised to use the Bubble Tube under supervision. You have to check the Tube periodically for ledge water under the Bubble Tube.

We are not responsible for any water damage, which is caused by the Bubble Tube

11. Related Products

Nenko interactive panel - 22009134

Interact with any of the Bubble Tubes.

Control the colors in the room and the flow of bubbles by pressing the different buttons.

Also compatible with the Nenko optic fibres , Nenko light source, other bubble units etc. to create an interactive area.



For more information, you can visit our website www.nenko.com

